



Similar framing in 3D

Given the area load is 50psf, find the line loads and point load on joist A above. That is, put the magnitudes on the free body diagram shown.