
UMass Amherst Digital Fabrication Lab Jamieson CMA-1080 Laser Cutter




Jamieson CMA-1080 Laser Cutter: Summary

The Jamieson CMA - 1080 CO2 Laser Summary uses a laser to cut and etch flat materials up to 1/4" thick. The laser is reflected through small mirrors and lenses which move around on small gantries. Through adjustments in the laser quality, speed, and power different affects can be created. However, the most common uses are for cutting and etching materials either through vector linework or raster images



Jamieson CMA-1080 Laser Cutter: Summary



Lab users cutting files on the machine shouldn't have to touch anything other then these parts.

STEP ONE: File Prep


To prepare files for the Jamieson laser cutter you need to setup your file in either Rhino or AutoCAD (or another CAD software). Start by creating different layers and giving them distinct names and colors. Some common layer types would be interior cuts, exterior cuts, and engraving. *You can expand on this list to include light engraving and dark engraving. Your various layer types will depend on what kind of file you're cutting.


Label your layers and set distinct colors in Rhino/
AutoCAD

Check your file for any


duplicates and delete them

The machine will not accept any files with points so select any points and delete them











The machine will also not accept files that have a z-value so you can use 'Setpt' or 'Project to CPlane' to make sure all your linework is planar







STEP TWO: Exporting your File

The Jamison laser cutter uses a dedicated program called *Smart Carve*. To import your file into this program you must export as a .dxf file


Export your linework to an AutoCAD Drawing Exchange file, a .dxf file and set the Export Scheme to CAM Imperial


File Edit View Curve Surface SubD Solid Mesh New...





When you open SmartCarve, you first need to select File and New. This will create a new work space/artboard for you to import your file.







STEP THREE: Setting up your file in SmartCarve

Next you need to set up your work space size and import your file.


To set up your work space, go to Tools and select Confia




The Jamieson machine works in mm units. The print bed is **980mm x 800mm** so in the work space area you need to confirm that these are the values listed and click OK



Once you confirm your work space size you can import your file. To do this go to File and Import File. This will open another dialogue box asking the drawing units of your original file. Select the units you used and click OK






STEP THREE: Setting up your file in SmartCarve

Next you will orient your linework on the work space and set up which layers will be doing what operations (i.e. cut or engraving)

When you import your linework it should snap down to the bottom left (0,0) point. It is usually a good idea to nudge it slightly inwards so there is 1/2"-1" border around your work. On the right side of the program you will find the layer color and laser settings.



When you import your work into SmartCarve it will assign your various layers to a new color and priority(order). As you can see in the settings window there are any number of colors and layers you can assign. It is recommended you keep to 2-3 layers as this will keep your file smaller.


ID	Color	Prior	Process	Visible	^
1		5	Yes	Yes	ı
2		4	Yes	Yes	
3		3	Yes	Yes	
4		2	Yes	Yes	
5		1	Yes	Yes	
6		6	Yes	Yes	
7		7	Yes	Yes	
8		8	Yes	Yes	
9		9	Yes	Yes	
10		10	Vac	Yan >	_ `
■ Layer Pa	rameter				
⊟ Layer Pa Name	rameter	6			
	rameter		128;0;0		
Name	rameter		128;0;0		
Name Color		-	128;0;0		
Name Color Priorty		6	128;0;0		
Name Color Priorty Process Visible		6 YES	128;0;0		
Name Color Priorty Process Visible	sing Media	6 YES YES	128,0;0		
Name Color Priorty Process Visible Process	sing Media	6 YES YES			
Name Color Priorty Process Visible Process	sing Media rameter el(mm/s)	6 YES YES Laser			

STEP THREE: Setting up your file in SmartCarve


In this window you will set your order of operations, normally engraving and interior cuts first and exterior cuts last. You will also set the speed and power settings for your various layers.


When you import your file into SmartCarve you may notice that the colors are different then your Rhino/AutoCAD file. This is okay as long as your layers still contain all their desired linework.

By adjusting the number in the priority input you can change the order of operations. i.e. changing the priority to 1 will cause that layer to be lasered first.



At the bottom of this window you'll find the speed and power settings, these are represented as mm/s and percentages respectfully. You will also see this machine uses variable power so there is a min and max value. You can find these settings on the provided settings sheet.





STEP FOUR: Preparing the Machine to Cut

You are now ready to prepare the machine to fun your file.

First you will turn on the machine with the Red Switch on the side of the machine. It will first run through a brief calibration cycle before it is ready to cut.



This will turn on the laser cutter as well as turn on the water chiller located next to the machine. If the chiller does not turn on, ask for help.



STEP FOUR: Preparing the Machine to Cut

There are a few quirks to this machine to keep in mind before you cut.

After you turn on the machine and before you run your file you will need to unplug the USB wire which runs to the Jamieson and then plug it back in. This reconnects the machine to the SmartCarve software





Another note is that the x-y directions shown on the SmartCarve software are different from the x-y directions on the Jamieson print bed. When orienting your work for the machine you need to keep in mind that the bed is rotated 180 degrees compared to the software.




STEP FOUR: Preparing the Machine to Cut


Next you need to focus the laser lens.







Unscrew the two screws holding the lens column. Lower it down so it sits on the Lens Focus Piece, re-tighten the screws, and slide the focus piece out from under the lens. This will correctly focus the laser beam. *Be sure not to adjust any other screws but the two for the lens column.




Next you need to make sure you turn on the compressor. The switch is on the wall to the left of the machine. This will send compressed air directed at the lens focus point to cool the cut.





STEP FIVE: Sending your File to Cut


You are now ready to cut your file.



Go back to the computer and on the top tool bar select the tool Carve Out. This will open the Path Optimize window which will prompt you to select which type of path to follow. Select the Path Optimize option.







This will open the Carve Out window, which provides some details of the file to be cut, including the time estimate. At the bottom is the Cut Edge button. Clicking this will have the machine run a simulated rectangle around the extents of your file. This is useful for making sure that your linework will fall on your material.

STEP SIX: Cutting your File


Make sure everyone in the lab has safety glasses on, activate the laser and begin your cut.




When running the laser cutter make sure that everyone in the lab has safety glasses on.

Make sure that the lid is closed and the compressor is on. You can then press the *Green Button* on the top of the machine, this is a safety switch which allows the laser to activate.







You can now go back to the Carve Out window on the computer and select Carver Out. This will start your file.

STEP SIX: Cutting your File


While your file is cutting you can use the control panel to pause, stop, and restart the file.



While the file is running, you can see the timer on the control screen. You can also click the STOP button to pause the file and the ESC button to end the file early if needed.



Before you collect your work piece and open the lid make sure to deactivate the laser using the green button.



You can now collect your file from the machine.

Jamieson CMA-1080 Laser Cutter: Closing Out



If you are done cutting for awhile you can turn off the compressor



And if you are done using the machine you can turn it off.

Jamieson CMA-1080 Laser Cutter: Troubleshooting				
Problem:	Cause:			
When you open up your file in SmartCarve and your linework has slight alterations and changes to it	You may have exported in the wrong format or used a different exporting scheme			

Solution: Make sure you are exporting as a .dxf file. Also make sure you are suing the export scheme CAM Imperial. Other schemes may alter your linework.

Jamieson CMA-1080 Laser Cutter: Troubleshooting

Jamieson CMA-1080 Laser Cutter:	irouplesnooting
Problem:	Cause:

Jamieson CMA-1080 Laser Cutter: Troubleshooting Solution:

Jamieson CMA-1080 Laser Cutter: Quick Step Quide

 Organize and Label Layers by Laser Cutter Operation ("cut", "etch"
 Set scale and prepare linework in Rhino or AutoCAD
 Export file as a .dxf and CAM Imperial
 Open SmartCarve and start a new file
 Check that the workspace is 980mm x 800mm
 Import your file and select the correct drawing u
 Arrange your linework on the workspace
 Set the Priority and Speed and Power settings for each of your layers
 Turn on the laser cutter and let it run through its calibration
 Make sure the water chiller also turns on with the laser cutter
 Unplug the USB and plug it back in
 Add your material to the laser cutter bed, use a ruler to align it
 Click the Carve Out button
 Click Path Optimize
 Flip the switch on the wall to turn on the Compressor
 Click the Cut Edge button to trace the extents of your file
 If your work piece is aligned turn ON the Green Activation button
 Put on Safety Glasses
 Click the Carver Out button to start your file
 Turn OFF the Green Activation button when your cut is done